


5800 VALVE

SPARE PARTS




Power head 5800/5810/5812

Item	Reference	Description	Packing qty
1	BR61832-00	Cover assy, 5800, 5810, 5812, black/blue	1
	BR61832-01	Cover assy, 5800, 5810, 5812, black/black	1
2	BR61836	Panel gear assy, 5800 DF/UF	1
	BR61957	Panel gear assy, 5810, 5812 DF/UF	1
3	62076	Timer assy 5800 Typhoon	1
	BR61833-01	Timer assy 5800 Storm TC	1
	BR61833-02	Timer assy 5800 Storm eco	1
	BR61833-03	Timer assy 5800 Storm TC UF	1
	BR61833-04	Timer assy 5800 Storm eco UF	1
	BR61833-05	Timer assy 5800 Storm filter UF	1
	61931-03	Timer Assy 5800 Hurricane w/ Pentair Logo	1
4	BR61835	Motor assy 5800	1
5	43262-00SP	Bezel, 5800 , Blue - (10 pc)	1
	43262-01SP	Bezel, 5800 , Black - (10 pc)	1
	BR44162	Transformer intl 230VAC-12VDC 5800	1
	BR61995	Optical sensor kit	1

5800 VALVE

SPARE PARTS



5800 spare parts

Item	Reference	Description	Packing qty
1	BR61857-01	Valve body assy 5800 filter	1
	BR61857-20	Valve body assy 5800 w/mixing	1
2	18569	Retainer tank seal	1
3	18303-01SP	O-ring Top of Tank - (10 pc)	1
4	13304-01SP	O-ring 560 CD - (10 pc)	1
5	13030SP	O-ring Retainer Resid - (50 pc)	1
6	18312SP	Retainer Drain - (10 pc)	1
7	VCINJ1	Injector residential - See VC sub-assemblies section	
8	BR61838	Piston assy, UF, 5800	1
	BR61837	Piston assy, DF, 5800	1
9	18261SP	Screw - (10 pc)	1
10	24509-01	Mixing assy resid	10
11	See PH page	Power head assy 5800	
12	60626-01	Meter assy 3/4" turbine SE/SXT	1
13	19569SP	Clip Flow Meter SXT - (12 pc)	1
14	13314SP	Screw Adapt Clip - (50 pc)	1
15	13709	Coupling assy 2510/resid/9000	2
16	13255SP	Mounting Clip - (12 pc)	1